

=====
apiJob("CAS","status_elv_werte","", "")

Satz : 0

OBJECT = cas
SAETZE = 1
JOBNAME = status_elv_werte
VARIANTE = CAS
JOBSTATUS =
UBATTCURRENT = -1
UBATTHISTORY = -1
IGNITIONCURRENT = -1
IGNITIONHISTORY = -1

Satz : 1

STAT_ELV_KL30L = 1.209961E+001
STAT_ELV_KL30E = 1.213162E+001
STAT_ELV_RESET_URSACHE = Reset-2 WD
STAT_ELV_SPEED = 10 Hz
STAT_ELV_SPEED_ZEIGER = 10 Hz
STAT_ELV_KL15EINDISC = 1 00 01 ..
STAT_ELV_WD_ENDISC = 0 00 00 ..
STAT_IN_KL3KMH_DISC = 0 00 00 ..
STAT_IN_ELVHW_DIAGDISC = 0 00 00 ..
STAT_ELV_MSG_BA = 0 00 00 ..
STAT_ELV_MSG_15 = 0 00 00 ..
STAT_IN_KL3KMH_DELAYDISC = 0 00 00 ..
STAT_ELV_SELBSTHEIL_AKTIV = 0 00 00 ..
STAT_ELV_ACTUEL_STATE = M_ELV_UNLOCKED
STAT_ELV = ENTRIEGELT
JOB_STATUS = OKAY
_TEL_ANTWORT = 38 Bytes

0000 : A2 F1 40 61 7A 7A 01 7B 01 20 95 01 10 08 00 00 çñ@azz.{ . ?.....
0010 : 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
0020 : 00 00 00 00 00 00 73s